




Safe and efficient heavy duty accessory to hold wheels removed while servicing vehicles on hoists.

WHEEL HOLDER

**M
O
L
N
A
R**



HOISTS



SECURI-T Restraint System

SAVES TIME

- Easy to install
- Holds the wheel right where you are working
- No need to lift or lower heavy wheels
- An essential accessory for today's professional workshop



FEATURES

- Built specifically to suit Molnar Two Post Hoists
- Capacity of 45kg
- Pivots in all directions to protect wheels and operators
- Four Wheel Holders per set

SECURI-T™

- Prevents wheels from dislodging even when vehicle is lowered to ground level
- 100% confidence in retaining wheels removed during servicing
- Designed & developed with professional mechanics

HOIST

PART NUMBER

ALL ROUNDER & BASE

5001005

FOUR TONNE

5001006

ASYMMETRIC

5001007

For Wheel Holder sets to suit other types of hoists, please contact Molnar Hoists

As the policy of Molnar Hoists is one of continuous improvement, the manufacturer reserves the right to change specifications without notice.



For more information, please contact us or your local Molnar Representative

T 08 7120 8700 F 08 8346 0097
E sales@molnarhoists.com.au
www.molnarhoists.com.au

onwards & upwards

