Designed to supplement the Molnar Hoist range, these lifting aids will improve workshop efficiency and safety

LIFTING AID ACCESSORIES

EP10		'Extension Pad'
	Provides valuable extra clearance for four-wheel-drives and vansLength160 mmWidth160 mmHeight - min180 mmHeight - max225 mm	For use on: Two Post Hoist Base Two Post Hoist All Rounder Two Post Hoist Asymmetric Two Post Hoist Four Tonne
JB11 & JB11A		
MOLNAR COL	Raise a vehicle for wheel free service optionsJB11JB11AWidth1100 mm1200 mmMax span1275 mm<	For use on: Four Post Hoists JB11A Wide version for 'A' series Refer Air Jacking Beam Accessories brochure for related accessories
PL92-RB & PL92-RB-40		'RUBBER BLOCKS' HOISTS
PL92-RB STANDARD PL92-RB-40 Low PRoFile	Solid rubber block for cushioned liftingPL92-RBPL92-RBPL92-RB-40Length150 mmWidth100 mmHeight70 mm	For use on: Platform Lift Scissor Lift Quick Lift Rubber Block Nest
SLO2-NEST		RUBBER BLOCK NEST'
	Nest to house rubber blocks Length 160 mm Width 100 mm Height 120 mm	 For use on: Four Post Rails Hoists Air Jacking Beam Scissor Lift with beam Ouick Lift with beam

JJ3 & J3

	2		
JJ3 Large		J3 SMALL	

abilises vehi	cle
113	J3
140 mm	100 m
30 mm	30 mr
80 mm	80 mr
	JJ 3 140 mm 30 mm

Stabilises vehicles on beams

Made from solid, long-lasting

90 mm

vulcanised rubber

Pad Height 30 mm

Diameter

'PICK-UP PADS'

For use on:

- Two Post Hoist Base
- TwoPost Hoist All Rounder
- Two Post Hoist Asymmetric
- Two Post Hoist Four Tonne

'Beam Pad'

For use on:

- Four Post Rails Hoists
- Air Jacking Beam
- Scissor Lift with beam
- Quick Lift with beam

nm m m

J3BP



Quick Lift with beam

Support and s	Support and stabilises vehicl		
	113		
Diameter	140 mm		
Height - min	30 mm		
Lloight may	<u>00 mm</u>		

	Ext-Pad		'Beam Riser, Standard
	Ext-Pad-Low	Provides valuable extra clearancefor four-wheel-drives and vansLength120 mmWidth100 mmHeight - min170 mmHeight - max215 mm	 For use on: Four Post Rails Hoists Air Jacking Beam Quick Lift with beam Scissor Lift with beam 'BEAM RISER, LOWERED
N		For vehicles with low clearanceLength120 mmWidth100 mmHeight - min140 mmHeight - max175 mm	For use on: Four Post Rails Hoists Air Jacking Beam Quick Lift with beam Scissor Lift with beam 'BEAM RISER, AXLE
A R	PL92-10	For stable pick-up on axle; cradle head prevents lateral movementLength120 mmWidth100 mmHeight - min150 mmHeight - max205 mm	For use on: Four Post Rails Hoists Air Jacking Beam Quick Lift with beam Scissor lift with beam 'PLATFORM RISER
HOISTS		Provides valuable extra clearancefor four-wheel-drives and vansLength120 mmWidth100 mmHeight - min155 mmHeight - max195 mm	For use on: ■ Platform Lift
	SLO2-SB		'Scissor Lift Beam
		Provides more pick-up optionsLength1550 mmWidth270 mmHeight55 mm	For use on: ■ Scissor Lift
	QLSB-02		'Quick Lift Beam
-		Provides more pick-up optionsLength1550 mmWidth270 mmHeight110 mm	For use on: ■ Quick Lift
	7252-023-01 & 7252-023-01 A		'Jack Stand
		Insert between platforms; can be to upside down and used as a tool tra 7252-023-01 7252-02 Length 1045 mm 1145 mm Width 225 mm < Height 60 mm	y ■ Four Post Hoists 3-01A ■ Four Post Rails Hoists

As the policy of Molnar Hoists is one of continuous improvement, the manufacturer reserves the right to change specifications without notice. For more information, please contact

60 mm

<

Height

us or your local Molnar Representative



T 08 7120 8700 F 08 8346 0097 E sales@molnarhoists.com.au www.molnarhoists.com.au

R ΗΟΙΣΤΣ

onwards & upwards