

Designed to supplement the Molnar Hoist Two Post Hoist range, these lifting aids will improve workshop efficiency and safety

TWO POST ACCESSORIES



EP10



'EXTENSION PAD'

Provides valuable extra clearance for four-wheel-drives and vans

For use on:

- Two Post Hoist Base
- Two Post Hoist All Rounder
- Two Post Hoist Asymmetric
- Two Post Hoist Four Tonne

Length _____ 160 mm
Width _____ 160 mm
Height - min _____ 180 mm
Height - max _____ 225 mm

JJ3



'PICK UP PAD, LARGE'

Supports and stabilises vehicle

For use on:

- Two Post Hoist Base
- Two Post Hoist All Rounder
- Two Post Hoist Asymmetric
- Two Post Hoist Four Tonne

Diameter _____ 140 mm
Height - min _____ 30 mm
Height - max _____ 80 mm

J3AB



'STABILISER PAD'

Auxiliary support for stability
Made from solid, long-lasting vulcanised rubber

For use on:

- Two Post Hoist Base
- Two Post Hoist All Rounder
- Two Post Hoist Asymmetric
- Two Post Hoist Four Tonne

Diameter _____ 100 mm
Pad Height _____ 30 mm

J3



'PICK UP PAD, SMALL'

Supports and stabilises vehicle

For use on:

- EXT-PAD
- EXT-PAD-LOW
- EP10

Diameter _____ 100 mm
Height - min _____ 30 mm
Height - max _____ 80 mm

For specific Quick Lift Two Post accessories, refer to the Quick Lift Accessories brochure

As the policy of Molnar Hoists is one of continuous improvement, the manufacturer reserves the right to change specifications without notice.

For more information, please contact us or your local Molnar Representative

T 08 7120 8700 F 08 8346 0097
E sales@molnarhoists.com.au
www.molnarhoists.com.au

onwards & upwards

